



SUPPLY ACTIVE 240VAC

NOTE  
USE ONLY THE CONNECTIONS SHOWN  
BELOW. DO NOT USE THE AUX TERMINAL

F27 TERMINAL  
BLOCK



PUMP MOTORS UP TO  
0.75kW (1hp) CAN BE DIRECTLY  
CONNECTED TO THE F27  
WITHOUT THE NEED FOR  
A CONTACTOR




CONTACTOR  
COIL 240VAC



PRESSURE  
SWITCH



CONTACTOR



FOR PUMP MOTORS LARGER THAN  
0.75kW (1 HP) USE A CONTACTOR TO  
DRIVE THE PUMP AND USE THE F27  
TO DRIVE THE CONTACTOR COIL AS  
SHOWN.

SUPPLY NEUTRAL

HOW TO CONNECT AN F27 TIME DELAY FLOW SWITCH TO A STANDARD PRESSURE SYSTEM TO GIVE  
THE SYSTEM LOSS OF FLOW PROTECTION

KELCO ENGINEERING Pty Ltd  
Phone 02 99056425  
Fax 02 99056420  
Email sales@kelco.com.au